



Item	Names	2HP	4HP	8HP	14HP	30HP
1	Side Plate (left or Right) (Size)	2HP-21-#	4HP-21-#	8HP-21-#	14HP-21-#	30HP-21-#
2	Drive Plate (left or Right) (Size)	2HP-22-#	4HP-22-#	8HP-22-#	14-HP-22-#	30HP-22-#
3	Ratchet (Size)	2HP-23-#	4HP-23-#	8HP-23-#	14HP-23-#	30HP-23-#
4	Side Plate Bushing (Not Shown) (Size)	NA	NA	NA	14HP-24-#	30HP-24-#
5	Primary Drive Pawl (Size)	2HP-25-#	4HP-25-#	8HP-25	14HP-25	30HP-25
6	Secondary Drive Pawl (Size)	2HP-26-#	4HP-26-#	8HP-26	14HP-26	30HP-26
7	Drive Pawl Spring	2HP-27	4HP-27	8HP-27	14HP-27	30HP-27
8	Drive Pin	2HP-28	4HP-28	8HP-28	14HP-28	30HP-28
9	Drive Pin Spring	2HP-29	4HP-29	8HP-29	14HP-29	30HP-29
10	Drive Plate Spring Pin (2 req.)	2HP-30	4HP-30	8HP-30	14HP-30	30HP-30
11	Reaction Pawl (Size)	2HP-31-#	4HP-31-#	8HP-31-#	14HP-31-#	30HP-31-#
12	Reaction Pawl Rotor	2HP-32	4HP-32	8HP-32	14HP-32	30HP-32
13	Reaction Pawl Rotor Spacer (Not Shown)	2HP-33	4HP-33	8HP-33	14HP-33	30HP-33
14	Reaction Pawl Spring Spacer	2HP-34	4HP-34	8HP-34	14HP-34	30HP-34
15	Reaction Pawl Spring	2HP-35	4HP-27	8HP-27	14HP-27	30HP-27
16	Top Spacer	2HP-36	4HP-36	8HP-36	14HP-36	30HP-36
17	Top Spacer Spring Pin	NA	4HP-37	8HP-37	14HP-37	30HP-37
18	Reaction Block (Size)	2HP-38-#	4HP-38-#	8HP-38-#	14HP-38-#	30HP-38-#
19	Shroud (Size)	2HP-39-#	4HP-39-#	8HP-39-#	14HP-39-#	30HP-39-#
20	Top Screws (4 Req.) (Not Shown)	2HP-40	HP-41	HP-42	HP-43	HP-44
21	Bottom Screws (4 Req.)(Not Shown)	HP-41	HP-42	HP-43	HP-44	HP-45
22	Reaction pad (Not Shown)	2HP-RP	4HP-RP	8HP-RP	14HP-RP	30HP-RP
23	Alco Arm (Not Shown)	2HP-ALC	4HP-ALC	8HP-ALC	14HP-ALC	30HP-ALC